

TM



8.2 Litre Performance Parts
Albuquerque, New Mexico
www.cad500parts.com

STAGE I SHAFT ROCKER ASSEMBLY

Congratulations ... You are the proud owner of one of the best rocker arm assembly available for the Cadillac 472/500/425 engine family. Though 'bulletproof' by design, special precautions should be taken to ensure a long and trouble free life for these assemblies. For reference, these rockers are 1.6:1 ratio, compared to the stock 1.65:1.

Please read all instruction thoroughly before installation - aluminum components and other parts may be damaged due to improper installation!

- ⊕ Pre-oil rocker assemblies before installation.
- ⊕ Take special care to seat all of the pushrod balls (the bronze end, if so equipped) into the cups as you tighten the mounting fasteners.
- ⊕ Torque to 32-35 Ft-Lbs. DO NOT OVER TORQUE!
- ⊕ Be sure to follow the firing order as you check the lifter lash or preload (15634278), and check them when the lifter is on the base circle of the cam (all the way down).
- ⊕ Rocker geometry is optimized by changing the installed height of the rocker shaft (via shimming or milling the supports) and checking the contact pattern of the rocker on the valve stem tip.
- ⊕ On hydraulic cams, adjust for a lifter preload of $\pm .020$ "-.060". Lifter preload is the distance the piston inside the lifter is pushed down away from the retaining clip. Accurate measurement can be difficult, but a good rule of thumb on a street motor is that it should look about like a spark plug gap. This can be adjusted via shimming / milling the shaft support(s), custom length pushrods, or adjusting the valve stem height by grinding the seats or valve stem tips. In most cases, you can get the correct pre-load by shimming the whole rocker assembly, with no machine work, and without causing a significant geometry problem.
- ⊕ If ordering your own custom pushrods, be sure to use 5/16" balls with oil holes. Other sizes may damage the rocker arms. The pushrods supplied are approx. 10".
- ⊕ Check for pushrod to head clearance - we generally drill out the pushrod holes in the head to 9/16" or 5/8" before assembly, to eliminate the potential clearance problem ahead of time. If you have already assembled your heads, the rocker arm location (side-to-side) may be adjusted by modifying the spacers.
- ⊕ Thank you for choosing Cad Company's Best Engineered Parts for the Cadillac 472", 500, and 425" engines. Feel free to call with any questions or suggestions _____

